

"The original makers of SMITHS instruments"

# Instructions for 80mm & 100mm 12volt Smiths Programmable Tachometers

### Caution Disconnect the negative battery cable prior to any installation

Caerbont Automotive Instruments Ltd Abercrave, Swansea, SA9 1SH, United Kingdom.

> Tel: +44-1639-732200 Fax: +44-1639-732201 www.caigauge.com

Products designed and manufactured under ISO 9001:2008 quality standard.

#### Installation Guide

For all programmable tachometers *except* SMITHS Flight, Prism and Motorsport types.

#### **Application Notes**

- For fitment to negative earth vehicles only.
- Operating voltage: 11 17volts DC
- Input signal:
   Petrol Engines
  - Contact breaker ignition (coil)
  - ECU tachometer output

#### Diesel Engines

- Alternator (W terminal)
- Calibration switch 8 should always be in the 'on' position.

## Caution Disconnect The Negative Battery Cable Prior To Any Installation

Harness connections								
Wire Colour	Pin No.	Connect to						
Brown/slate	1	Pull up for open collector ECU output						
Red/white	2	Illumination 12volt supply (side light feed)						
Red/blue	3	Tacho output from ECU or contact breaker or alternator 'W' terminal						
White/black	4	If your tacho fails to operate smoothly, the signal may be of a high sensitivity. Use the white/black wire <i>instead</i> of red/blue wire (above).						
Black	5	Ground/Chassis or battery negative						
Green	6	Switched ignition positive 12volt supply (via 3A fuse)						

#### <u>Calibration</u>

The tachometer is calibrated/programmed by setting a combination of seven switches located under the grommet on the back case. Remove the grommet to access the switches.

- The switch setting *must* be completed with the power off.

Notes:

- Set the switches prior to installing the tachometer.

The table overleaf shows the switch settings relative to the number of pulses per engine revolution.

To assist with the switch setting, the table below shows the number of pulses per engine revolution versus the number of cylinders for both single spark and 'wasted' spark ignitions.

#### Petrol Engines Only

	PPR - Pulses per Revolution								
Number of Cylinders	Single Spark Ignition	Wasted Spark Ignition							
1	0.5	1							
2	1	2 -							
3	1.5	3							
4	2	4							
6	3	6							
8	4	8							
10	5	10							
	6								

#### Diesel Engines Only

Pulses per engine revolution (PPR) is equal to the number of alternator pole pairs multiplied by the crank to alternator pulley ratio.

							PPR				Swit	ch sett	tings			No.	Switch settings No.
		Swi	tch setti	ngs			No.		sw1	sw2	sw3	sw4	sw5	sw6	sw7		sw1 sw2 sw3 sw4 sw5 sw6 sw7
sw1	sw2	sw3	sw4	sw5	sw6	sw7			_	^	0	0	1	1	^	12	0 0 0 0 1 1 21
_	_	_		_	_	_	^ -		1	0	_	0	1	1	0	12.1	1 0 0 0 1 1 21.25
0	0	0	0	0	0	0	0.5		١	0	0	0	1	1	0		0 1 0 0 1 1 21.5
1	0	0	0	0	0	0	1		4	1	0	0	1	1	0	12.2	1 1 0 0 1 1 21.75
0			0	_		_	1.5		1	1	0	0	1	1	0	12.3	0 0 1 0 0 1 1 22
1	1	0	0	0	0	0	2									12.4	4 0 0 4 22.25
. 0	0	1	0	0	0	0	3									12.5	0 4 4 00 5
1	0	1	0	0	0	0	4									12.6	4 4 0 0 4 22.75
0	1	1	0	0	0	0	5									12.7	0 0 1 1 22
1	1	1	0	0	0	0	6		0	0	0	1	1	1	0	12.8	
0	0	0	1	0	0	0	8		1	0	0	1	1	1	0	12.9	
							8.1		0	1	0	1	1	1	0	13	
							8.2		1	1	0	1	1	1	0	13.1	
							8.3		0	0	1	1	1	1	0	13.2	
							8.4									13.3	4 0 4 0 1 0 0 5
							8.5									13.4	0 1 1 0 1 24.5
																13.5	1 1 1 0 1 24.75
							8.6 8.7									13.6	0 0 0 1 1 25
							8.7									13.7	4 0 0 4 05 05
						_	8.8										0 1 0 1 1 0 5
							8.9									13.8	1 1 0 1 1 25.75
0	1	0	0	1	0	0	9									13.9	0 0 1 0 1 1 26
1	1	0	0	1	0	0	9.1									14	1 0 1 1 26 25
0	0	1	0	1	0	0	9.2									14.25	0 1 1 1 26 5
1	0	1	0	1	0	0	9.3		0	1	1	0	0	0	1	14.5	0 1 1 0 1 1 26.5
0	1	1	0	1	0	0	9.4	e La	1	1	1	0	0	0	1	14.75	1 1 1 1 1 26.75
							9.5		0	0	0	1	0	0	1	15	. 0 0 1 1 1 27
							9.6		1	0	0	1	0	0	1	15.25	1 0 0 1 1 1 27.25
	,						9.7		0	1	0	1	0	. 0	1	15.5	0 1 0 1 1 1 27.5
,	1	0	1	1	0	0	• •		1	1	0	1	0	0	1	15.75	1 1 0 1 1 1 27.75
4	1	0	1	1	0	0	9.9		0	0	1.	1	0	0	1	16	0 0 1 1 1 1 28
1	1	4	1	1 4	0	_			1	n	1	1	0	0	1	16.25	1 0 1 1 1 1 28.25
0	0	1	1	1	0					1	1	1	0	0	1	16.5	0 1 1 1 1 1 28.5
1	0	1	1	1	0	0			4	4	1	1	_	0	1	16.75	1 1 1 1 1 28.75
0	1	1	1	1	0	0	10.2		1	1	1	1	0	0	ا ا	10.75	O
1	1	1	1	1	0	0	10.3		0	0	0	0	1	0	1	47.05	Switch setting '1' signifies on
0	0	0	0	0	1	0	10.4		7	0	0	0	1	0	7	17.25	Switch setting '0' signifies off
1	0	0	0	0	1	0	10.5		0	1	0	0	1	0	1	17.5	
0	1	0	0	0	1	0	10.6		1	1	0	0	1	0	1	17.75	Setting example:
1	1	0	0	0	1	0	10.7		0	0	1	0	1.	. 0	1	18	
0	0	1	0	0	1	0	10.8		1	0	1	0	1	0	1	18.25	Four cylinder, single spark engine
1	0	1	0	0	1	0	10.9		0	1	1	0	1 1	0	1	18.5	PPR is 2
0	1	1	0	0	1	0	11		1	1	1	0	1	0	1	18.75	From table, switch setting is:
1	1	1	0	0	1	0	11.1		0	0	0	1	1	0	1	19	
^	^	^	1	0	1	, , , , , , , , , , , , , , , , , , ,	11 2		1	0	0	1	1	0	1	19.25	Sw1 sw2 sw3 sw4 sw5 sw6 sw7
4	0	0	4	0	4	0	11.2		· ·	1	. 0	1	1	n	1	19.5	1 1 0 0 0 0
							11.3									19.75	
							11.4										
-							11.5									20	
							11.6									20.25	Note: Switch number 8 should always be in the
1	0	1	1	0	1	0	11.7		0	1	1	1	1	0	1		'on' position.
_			4	^		^	44.0		1	1	1	1	1	Λ	1	20.75	J. PUJITI

0 1 1 0 1 1.8

1 1 1 0 11.9

on position.

PPR

20.75

PPR

*
,
*

#### MGB / Lotus Warning Lights

#### Speedometer or Tachometer

The HIGH BEAM Light is the White/Blue wire, to be connected to the +12V side of the high beam circuit. The Black Wire to true 0 Volts.

#### Tachometer

The IGNITION Light is the Brown/Yellow wire, to be connected to the alternator charge warning light output. The Green wire goes to +12v.

Included with the gauge is a 68 Ohm 5 watt resistor as some alternators require a load resistance to get them to charge. The wire colours of the resistor are matched to the gauge wiring colours, Green=12V & Brown/Yellow to the alternator charge warning light output. If required connect one end of the resistor to the warning light output on the alternator and the other end of the resistor to switched 12 volts.

#### Lotus Speedometer only

The single indicator light warning light has two inputs, Green/Red for LHS & Green/White for RHS, both are positive driven from the wires to the original warning light bulb. On negative earth vehicles the common Ground connector is internal to the gauge but for positive earth there is an extra external Black wire exiting the gauge.