

- Insert lamp into holder.
 It is essential to push the lamp and hold sembly fully into the lamp tube at the reuge The shoulder of the lamp holder / tt up to end of lamp tube.

