



# Caeront Automotive Instruments

The original makers of SMITHS Instruments

## Instructions for Chronoelectric Programmable Tachometers For Petrol and Diesel Engines

Independently tested and approved to 95/54/EC

Designed and manufactured under ISO9001:2000 quality standard

Caeront Automotive Instruments Ltd  
Abercrave, Swansea, SA9 1SH  
Tel: +44 (0) 1639 732200  
Fax: +44 (0) 1639 732201  
www.caigauge.com

### Application Notes

- For fitment to **negative earth** vehicles *only*.
- Operating voltage: 11 - 17volts DC
- Input signal:
  - Petrol Engines
    - Contact breaker ignition (coil)
    - ECU tachometer output
  - Diesel Engines
    - Alternator (W terminal)
- Calibration switch 8 should always be in the on position.

### Caution Disconnect The Negative Battery Cable Prior To Any Installation

Harness connections		
Wire Colour	Pin No.	Connect to
Green	1	Switched ignition positive 12volt supply (via 3A fuse)
Black	5	Chassis or battery negative
Red/white	4	Instrument illumination 12volt supply (side light feed)
White/black	6	Tacho output from ECU or contact breaker or alternator W terminal
Red/blue	7	Not used

### Calibration

The tachometer is calibrated/programmed by setting a combination of seven switches located under the grommet on the back case. Remove the grommet to access the switches.

Notes:

- The switch setting **must** be completed with the power off.
- Set the switches prior to installing the tachometer.

The table overleaf shows the switch settings relative to the number of pulses per engine revolution.

To assist with the switch setting, the table below shows the number of pulses per engine revolution versus the number of cylinders for both single spark and wasted spark ignitions.

#### Petrol Engines Only

#### PPR - Pulses per Revolution

Number of Cylinders	Single Spark Ignition	Wasted Spark Ignition
1	0.5	1
2	1	2
3	1.5	3
4	2	4
6	3	6
8	4	8
10	5	10
12	6	12

#### Diesel Engines Only

Pulses per engine revolution (PPR) is equal to the number of alternator pole pairs multiplied by the crank to alternator pulley ratio.

Switch settings							PPR No.
sw1	sw2	sw3	sw4	sw5	sw6	sw7	
0	0	0	0	0	0	0	0.5
1	0	0	0	0	0	0	1
0	1	0	0	0	0	0	1.5
1	1	0	0	0	0	0	2
0	0	1	0	0	0	0	3
1	0	1	0	0	0	0	4
0	1	1	0	0	0	0	5
1	1	1	0	0	0	0	6
0	0	0	1	0	0	0	8
1	0	0	1	0	0	0	8.1
0	1	0	1	0	0	0	8.2
1	1	0	1	0	0	0	8.3
0	0	1	1	0	0	0	8.4
1	0	1	1	0	0	0	8.5
0	1	1	1	0	0	0	8.6
1	1	1	1	0	0	0	8.7
0	0	0	0	1	0	0	8.8
1	0	0	0	1	0	0	8.9
0	1	0	0	1	0	0	9
1	1	0	0	1	0	0	9.1
0	0	1	0	1	0	0	9.2
1	0	1	0	1	0	0	9.3
0	1	1	0	1	0	0	9.4
1	1	1	0	1	0	0	9.5
0	0	0	1	1	0	0	9.6
1	0	0	1	1	0	0	9.7
0	1	0	1	1	0	0	9.8
1	1	0	1	1	0	0	9.9
0	0	1	1	1	0	0	10
1	0	1	1	1	0	0	10.1
0	1	1	1	1	0	0	10.2
1	1	1	1	1	0	0	10.3
0	0	0	0	0	1	0	10.4
1	0	0	0	0	1	0	10.5
0	1	0	0	0	1	0	10.6
1	1	0	0	0	1	0	10.7
0	0	1	0	0	1	0	10.8
1	0	1	0	0	1	0	10.9
0	1	1	0	0	1	0	11
1	1	1	0	0	1	0	11.1
0	0	0	1	0	1	0	11.2
1	0	0	1	0	1	0	11.3
0	1	0	1	0	1	0	11.4
1	1	0	1	0	1	0	11.5
0	0	1	1	0	1	0	11.6
1	0	1	1	0	1	0	11.7
0	1	1	1	0	1	0	11.8
1	1	1	1	0	1	0	11.9

Switch settings							PPR No.
sw1	sw2	sw3	sw4	sw5	sw6	sw7	
0	0	0	0	1	1	0	12
1	0	0	0	1	1	0	12.1
0	1	0	0	1	1	0	12.2
1	1	0	0	1	1	0	12.3
0	0	1	0	1	1	0	12.4
1	0	1	0	1	1	0	12.5
0	1	1	0	1	1	0	12.6
1	1	1	0	1	1	0	12.7
0	0	0	1	1	1	0	12.8
1	0	0	1	1	1	0	12.9
0	1	0	1	1	1	0	13
1	1	0	1	1	1	0	13.1
0	0	1	1	1	1	0	13.2
1	0	1	1	1	1	0	13.3
0	1	1	1	1	1	0	13.4
1	1	1	1	1	1	0	13.5
0	0	0	0	0	0	1	13.6
1	0	0	0	0	0	1	13.7
0	1	0	0	0	0	1	13.8
1	1	0	0	0	0	1	13.9
0	0	1	0	0	0	1	14
1	0	1	0	0	0	1	14.25
0	1	1	0	0	0	1	14.5
1	1	1	0	0	0	1	14.75
0	0	0	1	0	0	1	15
1	0	0	1	0	0	1	15.25
0	1	0	1	0	0	1	15.5
1	1	0	1	0	0	1	15.75
0	0	1	1	0	0	1	16
1	0	1	1	0	0	1	16.25
0	1	1	1	0	0	1	16.5
1	1	1	1	0	0	1	16.75
0	0	0	0	0	1	0	17
1	0	0	0	0	1	0	17.25
0	1	0	0	0	1	0	17.5
1	1	0	0	0	1	0	17.75
0	0	1	0	0	1	0	18
1	0	1	0	0	1	0	18.25
0	1	1	0	0	1	0	18.5
1	1	1	0	0	1	0	18.75
0	0	0	1	1	0	1	19
1	0	0	1	1	0	1	19.25
0	1	0	1	1	0	1	19.5
1	1	0	1	1	0	1	19.75
0	0	1	1	1	0	1	20
1	0	1	1	1	0	1	20.25
0	1	1	1	1	0	1	20.5
1	1	1	1	1	0	1	20.75

Switch settings							PPR No.
sw1	sw2	sw3	sw4	sw5	sw6	sw7	
0	0	0	0	0	1	1	21
1	0	0	0	0	1	1	21.25
0	1	0	0	0	1	1	21.5
1	1	0	0	0	1	1	21.75
0	0	1	0	0	1	1	22
1	0	1	0	0	1	1	22.25
0	1	1	0	0	1	1	22.5
1	1	1	0	0	1	1	22.75
0	0	0	1	0	1	1	23
1	0	0	1	0	1	1	23.25
0	1	0	1	0	1	1	23.5
1	1	0	1	0	1	1	23.75
0	0	1	1	0	1	1	24
1	0	1	1	0	1	1	24.25
0	1	1	1	0	1	1	24.5
1	1	1	1	0	1	1	24.75
0	0	0	0	1	1	1	25
1	0	0	0	1	1	1	25.25
0	1	0	0	1	1	1	25.5
1	1	0	0	1	1	1	25.75
0	0	1	0	1	1	1	26
1	0	1	0	1	1	1	26.25
0	1	1	0	1	1	1	26.5
1	1	1	0	1	1	1	26.75
0	0	0	1	1	1	1	27
1	0	0	1	1	1	1	27.25
0	1	0	1	1	1	1	27.5
1	1	0	1	1	1	1	27.75
0	0	1	1	1	1	1	28
1	0	1	1	1	1	1	28.25
0	1	1	1	1	1	1	28.5
1	1	1	1	1	1	1	28.75

Switch setting 1 signifies on  
Switch setting 0 signifies off

Setting example:

Four cylinder, single spark engine

PPR is 2

From table, switch setting is:

Sw1	sw2	sw3	sw4	sw5	sw6	sw7
1	1	0	0	0	0	0
On	on	off	off	off	off	off

**Note: Switch number 8 should always be in the on position.**